How to Upgrade the Controller ?

1. When the controller is turned off, press and hold the FN button, and connect the controller to the PC via the USB cable. The first indicator light of the controller turns yellow to enter the upgrade mode.
2. Unzip the compressed file, and open it. The upgrade interface will be shown as below picture.

3. Click “Update Firmware”.
4. The following dialog box pops up and click "(Y)" to upgrade.

5. Upgrading now, please kindly wait.

   * Note: It is prohibited to press the buttons or joysticks during the update.

6. After the upgrade is successful, the following dialog box pops up. The first indicator of the controller turns green, and the upgrade is complete.